



The controller should be installed in the place where is ventilated, waterproof and strong unit base. The base of the controller should be fixed on the metal surface with silicone which can guarantee heating dissipation, Before installation, cleaning the unit base, make sure no water no oil and no dust! The installation dimensions can adjust according to customer' requirement.

#### 4. Installing instruction

- ① BOYANG Controller;  
 ② Rated Voltage, V;  
 ③ Rated Power, W;  
 ④ Motor pole quantity
- BYC ( ) XX-XXX-X  
 ① ②-③ ④

#### 3. Name rules


14	Ambient temp.	-40℃~45℃
13	Type of cooling	fan cooling
12	Weight	1.5kg
11	Dimension	119mm*146mm*70mm
10	Grade of Protection	IPn4
9	Trouble light	LED (Option)
8	Connector	Analog voltage connector
7	Control mode	<p>◆The speed set-point is controlled by a zero to five volt analog non-isolated input. 0-5V Correspondence the minimum and maximum speed , 0.3v correspond the minimum speed,5v correspond the max speed;  <math>N=1000000 / (P * (2080-347 * (0.6 * Vin - 0.12)))</math>  N means speed; Vin means 0-5V Analog input (maximum is 5V , minimum is 0.3V,can start motor); P means Pole; 075series is 4 poles;135&amp;208series is 2 poles</p>
		<p>◆Fault signal output: Any problem above happen, the trouble light will flash; when controller works normally, the trouble light will be off.  ◆Counter-attack function: If the power wire connect incorrectly, the controller will be no damage; until connect correctly, the controller will work normally.</p>

than 5 times, otherwise motor need to power on again.

## 5. Fault Indicator Output

Item	Fault type	Light flash character	Remark
1	Over-heat	2 short 2 long	Short flash :
2	Under Voltage	3 short 2 long	flashing interval
3	Over Voltage	4 short 2 long	of 0.4 seconds;
4	Start up Failed	5 short 2 long	Long flash:
5	Low speed	2 short 3 long	flashing interval
6	Over-current	3 short 3 long	of 0.7 seconds.
7	Inner temp protection	4 short 3 long	
8	External temp protection	5 short 3 long	

Item	Fault Phenomenon	Measurement
1	Motor reversal	Stop the motor, change any 2 wires of the three motor wires, then restart motor.
2	Motor no work	Make sure the connecting of motor wires is correct, and the voltage also need to check
3	The speed is unnormal	Make sure whether voltage is over-low or load too much .
4	Motor stop suddenly	Make sure voltage over-high or over-low; over load or over heat.
5	Motor can't startup or restart	Make sure the connecting of motor wires is correct, and the voltage also need to check.
6	Trouble light flash	System over-load or short-circuit or other protection



KVB-075Z24-KJX

BLDC-A

KVB135 Z24-4K1X